# Installation Mars LED Panel Light



## LED Panel Light Installation Instructions Graph


#### Notes before Installation:

- 1. It must be professional electrician who has certificate can install the products.
- 2. Please confirm if the products are keeping well before taking out of packing.
- 3. There must be 0.2m distance between the products and inflammable material, To make sure high and low voltage electrical attachment separate.
- 4. The wires behind the lamps can be fixed with cable clip to make sure it positive anchoring
- 5.To make sure the length of the lamps is enough ,don't be caugh with stretching force or tangential force .Avoid Excessive tension when installing the lamp and connecting the wires ,don't knot the wire.Please tell the input and output wires and don't mix up with other
- 6. After installation, connect the input end of the lamp with the output end of the Switching Power Supply .
- 7. Connect the Input end of Switching Power Supply with electric supply, Usually Brown line is the power line, bule line is zero line, yellow line is ground wire.
- 8. Don't blended the Special drive for led lamp with other lamps.


## Installation Step as Follows:


### A.In-Built:

1. Take off Celling plaster tablet (as picture 1) 2. Connect the Wire(as picture 2)




3. Fix the panel Light on into the celling screens (as picture 3)





4. After steady the panel light, you can connect the electric current to use (as picture 4)




## Installation **Mars LED Panel Light**




## B.Celling Type:

1. Fix the celling frame into the celling or wall(as picture 1)




(Picture 1)

3. Fix the panel light on the celling frame(as picture 3)




2. Connect the wire(AC/DC Wire) and put the location well(as picture 2)




(Picture 2)

4. After steady the panel light, you can connect the electric current to use (as picture 4)




## C. Hanging Type:

1. Take off the cassette and install the screw cassette(as picture 1)




(Picture 1)

3. Lock the Line controler into the cassette(as picture 3)




(Picture 3)

2. Fix the cassette onto the celling(as picture 2)



(Picture 2)

4. Adjust the length of the iron line well and then connect the power supply ,then you can power(as picture 4)



(Picture 4)